

TIME CHANGE FOR SV 8100

CLOCK/CALENDAR SETTING

*

**ALL TIME CHANGES MUST BE MADE FROM THE MAIN
PHONE**

TO SET THE SYSTEM TIME:

1. PRESS THE SPEAKER KEY AT THE MAIN PHONE
2. DIAL 728
3. DIAL TWO DIGITS FOR THE HOUR (24 HR CLOCK)
EXAMPLE: 13 = 1PM, 14 = 2PM, 15 = 3PM, ETC.
4. DIAL TWO DIGITS FOR THE MINUTES (00 – 59)
5. PRESS SPEAKER TO HANG UP

NOTE

**ADJUSTING THE CALENDAR DATE REQUIRES A TECHNICIAN
THIS CHANGE CAN ONLY BE DONE IN PROGRAMMING**