SETTING PRO I CLOCK/CALENDAR SETTING

(THIS PROGRAMMING MUST BE DONE FROM EXTENSION 10)

- 1.) PRESS FEATURE/FNC KEY
- 2.) ENTER 9#
- 3.) ENTER HOUR AND MINUTE AS FOUR DIGITS USING THE DIAL PAD KEYS
- 4.) PRESS RECALL KEY TO CHANGE AM/PM SETTING
- 5.) PRESS HOLD KEY TO SWITCH TO CALENDAR SETTING OR PRESS FEATURE/FNC KEY TO EXIT PROGRAMMING
- 6.) IF SETTING CALENDAR, PRESS RECALL KEY TO SELECT THE DAY OF THE WEEK
- 7.) PRESS "#" KEY TO MOVE THE CURSOR TO THE DAY OF THE MONTH FIELD
- 8.) ENTER THE DAY OF THE MONTH USING THE DIAL PAD KEYS
- 9.) PRESS RECALL KEY TO SELECT THE MONTH
- 10.) PRESS "#" KEY TO MOVE THE CURSOR TO THE YEAR FIELD
- 11.) ENTER THE LAST TWO DIGITS OF THE YEAR USING THE DIAL PAD KEYS
- 12.) PRESS FEATURE/FNC KEY TO SAVE